

Personal Alarms & Security Products

Protect yourself and your loved ones'

with the **WALK EASY** **WHITE KNIGHT**

Electronic Personal Alarm



WALK EASY Product Code: 5-625

**Simple to
operate**



**Long
battery life**

APPLICATIONS

Women, children, nurses, students, walkers, joggers, cyclists, campers, all persons in hazardous areas or situations, persons carrying cash and valuable documents or items, public transport workers, the elderly or disabled and those living alone.

SPECIFICATION

Decibel (sound) Level: 136dB(a) Colour: White

Height: 69mm. Width: 61mm. Depth: 34mm. Weight: 90gms (3.2ozs)

Battery: 9 volt Heavy Duty (PP3 or equivalent)

FEATURES

Small & light weight, and can be used as a handbag snatching alarm

Simple to use - pull the rip-cord to operate

Integral belt or pocket clip on the back of the alarm

Extremely loud 'Audio Siren' & very strong 'ABS Plastic' Casing

12 months guarantee (excluding battery)

Stable and reliable digital technology

No power consumption when not in use

Supplied with a fitted battery with a 2 hour battery life on activation

See reverse for further details

The WALK EASY 5-625 WHITE KNIGHT ELECTRONIC PERSONAL ALARM

The Walk Easy 5-625 Electronic Personal Alarm has passed the Electromagnetic Compatibility (EMC) test required by EC Council Directive 89/336/EEC (UK Regulations S.I. 1992/2372) and Directive 92/31/EEC2

Complete with a 9 volt fitted battery, compact, powerful and efficient, the Walk Easy White Knight Personal Alarm is invaluable in all distress situations. Just pull the ripcord for an ear piercing alarm audible up to 1/4 mile away. Police and security advisors recommend the use of Personal Alarms to minimise the threat of assault, rape, mugging, animal attack or obscene phone calls.

INSTRUCTIONS

To operate your Walk Easy White Knight Personal Alarm: simply pull the ripcord to remove the pin. The alarm will be activated immediately the pin is removed and will only stop when the pin is replaced. The Alarm will run for up to 2 hours with a fresh battery.

WARNING

The effectiveness of the Walk Easy 5-625 Personal Alarm is in part due to its extremely loud and powerful siren, which produces 136 decibels of sound at source (125 decibels is the normal pain threshold of human hearing). As a result, prolonged exposure can cause permanent hearing damage.

DO NOT ACTIVATE THE ALARM UNNECESSARILY.

In particular take care to avoid endangering small children and pets.

The manufacturer and its agents will not accept any responsibility for any loss, damage or personal injury sustained while in possession of this product whatever the cause or reason.

TO CHANGE THE BATTERY IN YOUR WALK EASY WHITE KNIGHT ELECTRONIC ALARM

1. Remove the two Phillips screws in the back of the alarm.
2. Remove the back cover and replace the battery ensuring that the new battery is inserted correctly.

NOTE: Incorrect insertion of the battery will prevent your alarm from working properly and may damage the alarm.

3. Replace back cover and insert and re-tighten the screws.
4. Always test the alarm after changing the battery.

POWER SUPPLY

To ensure that your alarm is always at the peak of efficiency, please: Check the battery's condition regularly by activating the alarm for a short period. At the first sign of a weak sound, replace the battery with a new 9 volt heavy duty battery, (PP3 or equivalent).

SUGGESTIONS FOR USE

The Walk Easy 5-625 Electronic Personal Alarm can be held simply in your hand with the cord slipped around your wrist. Alternatively, it is fitted with a clip on the rear of the alarm which can be used to attach it to a belt, pocket or waistband for personal security protection, or to a handbag or other item of luggage for protection against theft.

GUARANTEE

The Walk Easy WHITE KNIGHT Personal Alarm, excluding battery, is guaranteed against defects in materials and workmanship in normal use for a period of one year from the date of purchase. This guarantee is only valid if the alarm has not been altered, modified or repaired by anyone other than the manufacturer, and is also invalidated where a replacement battery has been incorrectly fitted. This guarantee does not affect your statutory rights.

please see reverse for further details